

Sash width (W)	Free width (w)
	$w = W - 100\text{mm}$
Sash height (H)	Free height (h)
	$h = H - 100\text{mm}$