

Sash width (W), when	Free width (w)
0-85mm setback from the façade	$w = W - 250\text{mm}$
85-225mm setback from the façade	$w = W - 270\text{mm}$
> 225mm setback from the façade	$w = W - 310\text{mm}$
Sash height (H)	Free height (h)
	$h = H - 100\text{mm}$