

Sash width (W)	Free width (w)
	$w = W - 100\text{mm}$
Sash height (H)	Free height (h)
885 - 974.9mm	$h = H - 375\text{mm}$
975 - 1600mm	$h = 0.652 \times H - 34\text{mm}$