

Sash width (W)

Free width (w)

Standard, DGU

$$w = W1 + W2 - 418\text{mm}$$

Sash height (H)

Free height (h)

$$h = H - 102\text{mm}$$